CONTENTS

4 SAFETY INFORMATION
6 ENVIRONMENT CONCERNS
6 TECHNICAL INFORMATION
7 PRODUCT DESCRIPTION
7 ACCESSORIES
8 CONTROL PANEL
13 PROGRAMMES
17 BEFORE FIRST USE
17 USING THE APPLIANCE
17 LOADING THE LAUNDRY
18 FILLING THE DETERGENT AND ADDITIVES
19 SETTING AND STARTING A PROGRAMME
20 AT THE END OF THE PROGRAMME
22 HELPFUL HINTS AND TIPS
24 CARE AND CLEANING
29 TROUBLESHOOTING
32 INSTALLATION

SERVICE

When contacting Service, ensure that you have the following data available. The information can be found on the rating plate.

Model _____
PNC _____
Serial Number _____

The following symbols are used in this user manual:

⚠
Warning - Important Safety information.

i
General information and tips

Environmental information

Subject to change without notice

FOR PERFECT RESULTS

Thank you for choosing this AEG product. We have created it to give you impeccable performance for many years, with innovative technologies that help make life simpler – features you might not find on ordinary appliances. Please spend a few minutes reading to get the very best from it.

ACCESSORIES AND CONSUMABLES

In the AEG webshop, you'll find everything you need to keep all your AEG appliances looking spotless and working perfectly. Along with a wide range of accessories designed and built to the high quality standards you would expect, from specialist cookware to cutlery baskets, from bottle holders to delicate laundry bags…

Visit the webshop at:
www.aeg.com/shop

VISIT OUR WEBSITE FOR:

- Products
- Brochures
- User manuals
- Trouble shooter
- Service information

www.aeg.com

SAFETY INFORMATION

Before the installation and use, read this manual carefully:

- For your safety and the safety of your property
- To help the environment
- For the correct operation of the appliance.

Always keep these instructions with the appliance also if you move or give it to a different person.
The manufacturer is not responsible if an incorrect installation and use causes damage.

CHILDREN AND VULNERABLE PERSON SAFETY

- Do not let persons, children included, with reduced physical sensory, reduced mental functions or lack of experience and knowledge use the appliance. They must have supervision or instruction for the operation of the appliance by a person who is responsible for their safety. Do not let children play with the appliance.
- Keep all packaging away from children. There is the risk of suffocation or injury.
- Keep all detergents away from children.
- Keep children and pets away from the appliance when the door is open.
- Before you close the appliance door, make sure that children and pets are not into the drum.
- If the appliance has a child safety device, we recommend to activate it.

CHILD SAFETY DEVICE

- When you activate this device, you cannot close the door. This prevents children or pets to be closed in the drum. To activate the device, turn it clockwise, until the groove is horizontal. To deactivate the device, turn it counterclockwise, until the groove is vertical.



GENERAL SAFETY

- Do not use the appliance for professional use. The appliance is only for domestic use.
- Do not change the specifications of this appliance. There is the risk of injury and damage to the appliance.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance. Risk of explosion or fire.
- Obey the safety instructions on the detergent packaging to prevent burns to eyes, mouth and throat.
- Make sure that you remove all metal objects from the laundry. Hard and sharp material can cause damage to the appliance.
- Do not touch the glass of the door while a programme operates. The glass can be hot (only for front-loading appliances).

CARE AND CLEANING

- Deactivate the appliance and disconnect the mains plug from the mains socket.
- Do not use the appliance without the filters. Make sure that the installation of the filters is correct. An incorrect installation causes water leakages.

INSTALLATION

- The appliance is heavy, be careful when you move it.
- Do not transport your appliance without the transit bolts, you can damage

internal components and cause leakages or malfunctions.
- Do not install and connect a damaged appliance.
- Make sure to remove all packaging and transport bolts.
- Make sure that the mains plug is disconnected from the mains socket during installation.
- Only a qualified person must do the electrical installation, the plumbing and the installation of the appliance. This to prevent the risks of structural damage or injury.
- Do not install or use the appliance where the temperature is less than 0 °C.
- When you install the appliance on a carpet floor, make sure that there is air circulation between the appliance and the carpet. Adjust the feet to have the necessary space between the appliance and the carpet.

Water connection

- Do not connect the appliance with old hoses already used. Only use new hoses.
- Make sure not to cause damage to the water hoses.
- Do not connect the appliance to new pipes or pipes not used for a long time. Let the water flow for some minutes, then connect the inlet hose.
- The first time you use the appliance, make sure that the water hoses and the couplings do not have leakages.

Electrical connection

- Make sure that the appliance is earthed.
- Make sure that the electrical information on the rating plate agrees with the power supply.
- Always use a correctly installed shockproof socket.
- Do not use multiple plugs and extension cables. There is a risk of fire.
- Do not replace or change the mains cable. Contact the service centre.
- Make sure not to cause damage to the mains plug and cable.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.

DISCARD THE APPLIANCE

1. Disconnect the mains plug from the mains socket.
2. Cut off the mains cable and discard it.
3. Discard the door catch. This prevents children or pets to be closed in the appliance. There is a risk of suffocation (only for front-loading appliances).

ENVIRONMENT CONCERNS

PACKAGING MATERIALS

Recycle the materials with the symbol ♺.
Put the packaging in applicable containers to recycle it.

ECOLOGICAL HINTS

To help the environment, use less water and energy, obey these instructions:

- Set a programme without the prewash phase to wash laundry with normal soil.
- Always start a washing programme with the maximum load of laundry.
- If necessary, use a stain remover when you set a programme with a low temperature.
- To use the correct quantity of the detergent, check the water hardness of your domestic system

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council, your household waste disposal service or the shop where you purchased the product.

TECHNICAL INFORMATION

Dimensions	Width / Height / Depth	600 / 850 / 605 mm
	Total depth	640 mm
Electrical connection:	Voltage Overall power Fuse Frequency	230 V 2200 W 10 A 50 Hz
Level of protection against ingress of solid particles and moisture ensured by the protective cover, except where the low voltage equipment has no protection against moisture		**IPX4**
Water supply pressure	Minimum	0,5 bar (0,05 MPa)
	Maximum	8 bar (0,8 MPa)
Water supply [1]		Cold water
Maximum load	Cotton	8 kg
Spin speed	Maximum	1400 rpm

[1] Connect the water inlet hose to a water tap with a 3/4'' thread.

PRODUCT DESCRIPTION





1. Worktop
2. Detergent dispenser
3. Control panel
4. Door handle
5. Rating plate
6. Drain pump
7. Feet for the appliance level
8. Water drain hose
9. Water inlet valve
10. Mains cable
11. Transit bolts
12. Feet for the appliance level

ACCESSORIES



1. **Spanner**
   To remove the transit bolts.
2. **Plastic caps**
   To close the holes on the rear side of the cabinet after the removal of the transit bolts.
3. **Anti-flood inlet hose**
   To prevent possible leakage
4. **Plastic hose guide**
   To connect the drain hose on the edge of a sink.

CONTROL PANEL



1 On/Off button (**Auto Off**)
2 Programme knob
3 Display
4 Start Pause button (**Start/Pause**)
5 Delay start button (**Tidsforvalg**)
6 Time saving button (**Spar Tid**)
7 Extra rinse button (**Ekstraskyll**)
8 Stain/Prewash button (**Flekker / Forvask**)
9 Spin reduction button (**Sentrif.**)
10 Temperature button (**Temp.**)

AUTO OFF BUTTON 1

Press this button to activate or deactivate the appliance. A tune sounds when the appliance is activated.
The AUTO OFF function automatically deactivates the appliance to stop the energy consumption when:

- You do not use the appliance for 5 minutes before you press button 4 .
  – All settings are cancelled.
  – Press button 1 to activate the appliance again.
  – Set again the washing programme and all possible options.
- After 5 minutes from the end of the washing programme. Refer to 'At the end of programme'.

PROGRAMME KNOB 2

Turn this knob to set a programme. The related programme indicator comes on.

DISPLAY 3



The display shows:

A	88	The temperature of the set programme
	✳	Cold water
B	1888	The spin speed of the set programme
	– – –	No Spin symbol[1)]
	⊓	Rinse Hold symbol

[1)] Only available for Spin/Drain programme.

C	I	Prewash phase
	II	Washing phase
	≋	Rinses phase
	◎	Spin phase

The phase symbols

- When a programme is set, all the symbols of the phases related to the programme come on.
- When the programme starts, only the symbol of the phase in operation flashes.
- When the programme is completed, the symbol of the last phase is on.

D	♨	The steam symbol comes on when you set a Steam programme.
E		The detergent overdosing comes on at the end of the cycle when the appliance detects too much detergent.

F		You cannot open the appliance door when the symbol is on. You can open the door only when the symbol goes off. **If the programme is completed but the symbol stays on:** • The 'Rinse Hold' function is on. • There is water in the drum.
G		The delay start symbol comes on when you set the delay start function.
H		• The programme time When the programme starts, the programme time decreases with steps of 1 minute.
		• The delay start When you press the delay start button, the display shows the delay start time.
		• Alarm codes If the appliance has a malfunction, the display shows alarm codes. Refer to 'Troubleshooting'.
		• The display shows this message for some seconds when: – You set a function that is not applicable for the programme. – You change the programme while it operates.
		• When the programme is completed.
I		The child safety lock symbol comes on when this device is activated.

Graphic bars

		The empty indicator bar appears only if the related function is available for the set programme.
		The indicator bar fills accordingly to the set functions.
	If you make a wrong selection the message **Err** indicates that the selection is not possible.	
J		The time save symbol comes on when you set one of the programme duration:
		• Shortened duration
		• Extra Quick
K		The extra rinse symbol comes on when this function is activated.
		The value shows the total number of the rinses.

		The indicator bar is fully filled when you set to the maximum number of rinses.
L		The Stain symbol comes on when you activate the function.
		The Prewash symbol comes on when you activate the function.
		The indicator bar is not fully filled when you set only one of the functions.
		The indicator bar is fully filled when you set the two functions.

START/PAUSE BUTTON 4

Press button 4 to start or interrupt a programme.

DELAY START BUTTON 5

Press button 5 to delay the start of a programme from 30 minutes to 20 hours.

TIME SAVE BUTTON 6

Press button 6 to decrease the duration of the programme.

– Press one time to set 'Shortened duration' for items with daily soil.
– Press two times to set 'Extra Quick' for items with light soil.

Some programmes accept only one of the two functions.

EXTRA RINSE BUTTON 7

Press button 7 to add rinsing phases to a programme.
Use this function for persons allergic to detergents and in areas where the water is soft.

THE STAIN-PREWASH BUTTON 8

Press button 8 to add the stain and/or a prewash phase to a programme.
Press the button again and again to activate one or two options. The related symbol and the indicator bar comes on in the display.

STAIN

- Use this function for laundry with hard stains to remove.

  When you set this function, put the stain remover into compartment . This function increases the programme duration.

This function is not available with a temperature lower than 40° C.

PREWASH

- Use this function to add a prewash phase before the washing phase. We recommend that you use this function when you have laundry with a high level of soil.

The set of this function increases the programme duration.

SPIN BUTTON 9

Press this button to:

- Decrease the maximum speed of the spin phase of the programme.

The display shows only the spin speeds available with the set programme.

- Deactivate the spin phase.
- Activate the 'Rinse Hold' function. Set this function to prevent fabric creases. The appliance does not drain the water when the programme is completed.

TEMPERATURE BUTTON 10

Press button 10 to change the default temperature. When the display shows

✳ - -, the appliance does not heat the water.

ACOUSTIC SIGNALS FUNCTION

You can hear the acoustic signals when:

- You activate the appliance.
- You deactivate the appliance.
- You press the buttons.
- The programme is completed.
- The appliance has a malfunction.

To **deactivate/activate** the acoustic signals, press button 8 and button 7 at the same time for 6 seconds.

If you deactivate the acoustic signals, they continue operate only when you press the buttons and when a malfunction occurs.

CHILD LOCK FUNCTION

This function prevents children to play with the control panel.

- To activate the function, press button 10 and button 9 at the same time until the display shows the symbol .
- To deactivate the function, press button 10 and button 9 at the same time until the symbol goes off.

You can activate the function:

- Before you press the Start/Pause button 4 : the appliance cannot start.
- After you press the Start/Pause button 4 , all the buttons and the programme knob are deactivated.

PERMANENT EXTRA RINSE FUNCTION

With this function you can keep the extra rinse function permanently on when you set a new programme.

- To **activate** the function press button 6 and button 5 at the same time until the display shows the symbol .
- To **deactivate** the function press button 6 and button 5 at the same time until the symbol goes off.

PROGRAMMES

Programme Temperature	Type of load Max. weight of load	Cycle description	Functions
Koke-/ Kulørt 95° - 0°	White and coloured cotton with normal soil. max. load 8 kg	Wash Rinses Long spin	SPIN REDUCTION SKYLLESTOPP FORVASK[1)] EKSTRA SKYLL FLEKKER[2)] SPAR TID[3)]
Ekstra Stille 95° - 0°	White and coloured cotton with normal soil. max. load 8 kg	Wash Stop with water in the drum Rinses	FORVASK[1)] EKSTRA SKYLL FLEKKER[2)] SPAR TID[3)]
Lettstelt 60° - 0°	Synthetic or mixed fabric items with normal soil. max. load 4 kg	Wash Rinses Short spin	SPIN REDUCTION SKYLLESTOPP FORVASK[1)] EKSTRA SKYLL FLEKKER[2)] SPAR TID
Strykelett[4)] 60 - 0°	Synthetic fabrics with normal soil. max. load 4 kg	Wash Rinses Short spin	SPIN REDUCTION SKYLLESTOPP FORVASK[1)] EKSTRA SKYLL SPAR TID
Finvask 40 - 0°	Delicate fabrics as acrylics, viscose, polyester items with normal soil. max. load 4 kg	Wash Rinses Short spin	SPIN REDUCTION SKYLLESTOPP FORVASK[1)] EKSTRA SKYLL FLEKKER[2)] SPAR TID
Ull / Silke 40 - 0°	Machine washable wool. Hand washable wool and delicate fabrics with «hand washing» care symbol. max. load 2 kg	Wash Rinses Short spin	SPIN REDUCTION SKYLLESTOPP
Sengeteppe 60 - 30°	One synthetic blanket, duvet, bedspread and so on. max. load 3 kg	Wash Rinses Short spin	SPIN REDUCTION

Programme Temperature	Type of load Max. weight of load	Cycle description	Functions
Antiallergi 60°	White cotton items. This programme removes micro-organisms thanks to the washing by 60° C and adds on rinse. In this way the wash is more effective. Put a special additive for hygiene in the Stain compartment and set the Stain function. max. load 8 kg	Wash Rinses Long spin	SPIN REDUCTION SKYLLESTOPP FORVASK[1)] FLEKKER[2)] EKSTRA SKYLL
Sentr./ Tømming[5)] 0°	All fabrics. The maximum load of the laundry is related to the type of laundry. max. load 8 kg	Drainage of the water Spin phase.	SPIN REDUCTION
Skylling 0°	All fabrics. max. load 8 kg	One rinse with additive Spin phase	SPIN REDUCTION SKYLLESTOPP EKSTRA SKYLL[6)]
Jeans 60° - 0°	All items in jeans. Jersey made items with hi-tech materials. max. load 8 kg	Wash Rinses Short spin	SPIN REDUCTION SKYLLESTOPP FORVASK[1)] EKSTRA SKYLL
20 Min. - 3 kg 40° - 30°	Cotton and synthetic items with light soil or worn only one time. max. load 3 kg	Wash Rinses Short spin	SPIN REDUCTION
Super Eco[7)] 0°	Mixed fabrics (cotton and synthetic items). max. load 3 kg	Wash Rinses Short spin	SPIN REDUCTION SKYLLESTOPP EKSTRA SKYLL
Energisparing[8)] 60° and 40°	White and fast coloured cotton with normal soil. max. load 8 kg	Wash Rinses Long spin	SPIN REDUCTION SKYLLESTOPP FORVASK[1)] FLEKKER[2)] EKSTRA SKYLL SPAR TID[3)]

1) If you use liquid detergent, set a programme without PREWASH.

2) The Stain function is not available with a temperature lower than 40°C.

3) If you set the «Ekstra kort» duration, we recommend that you decrease the quantity of the load. It is possible to load fully the appliance, however the washing results are reduced.

4) The wash and spin phase of this programme is soft to prevent the creases of the laundry. The appliance adds some rinses.

5) Set the spin speed. Make sure that it agrees with the laundry. To select the DRAIN programme only, set the function NO SPIN.

6) Press EXTRA RINSE button to add rinses. With a low spin speed the appliance performs delicate rinses and a short spin.

7) Set this programme to decrease the time and the consumption of energy and water. Use a special detergent for very low temperature.

8) Set this programme to have good washing results and decrease the energy consumption. The time of the washing programme is extended.

STEAM PROGRAMMES

Programme[1)]	Type of load	Max. load
Damp Antikrøll This cycle removes odours from the laundry. Steam does not remove animal odours.	Cotton and synthetic items.	up to 1.5 Kg
Damp Oppfriskning This cycle helps to dewrinkle the laundry.	Cotton and synthetic items.	up to 1.5 Kg

Steam can be used for dried, washed or worn once laundry. These programmes can reduce creases and odours and make your laundry more soft.
Do not use any detergent. If necessary, remove stains by washing or using localized stain removal.
Steam programmes do not perform any hygienic cycle.

Do not set the Steam programme for this type of items:

- items where it is not specified on the care label as being suitable for tumble-drying
- all items with plastic, metal, wooden parts or alike.

1) If you set a Steam programme with dried laundry, at the end of the cycle the laundry feels humid. It is better to expose items to the fresh air for about 10 minutes to let the humidity dry. When the programme is completed, quickly remove the laundry from the drum. After a steam cycle, items may to be ironed anyway, but with less effort!

CONSUMPTION VALUES

Programme[1)]	Energy consumption (KWh)[2)]	Water consumption (litre)[2)]
White Cottons 95 °C	2.4	70
Cottons 60 °C	1.50	66
Cottons 40 °C	0.90	66
Synthetics 40 °C	0.60	48
Delicates 40 °C	0.70	58
Wool/ Handwash 30 °C	0.35	57

1) Refer to the display for the programme time.

[2] The consumption information shown in this chart is indicative. It can vary depending on the quantity and the type of laundry, on the temperature of the water supply and on the ambient temperature.

Standard programmes for the Energy Label consumption values

The cotton 60 °C economy and cotton 40 °C economy are the standard cotton programmes for normally soiled cotton laundry. They are suitable to clean normally soiled cotton laundry and they are the most efficient programmes in terms of combined energy and water consumption for washing that type of cotton laundry.
They agree with EN60456.

The actual water temperature may differ from the declared cycle temperature.

BEFORE FIRST USE

1. To activate the drain system, put 2 litre of water in the main wash compartment of the detergent dispenser.
2. Put a small quantity of detergent in the main wash compartment of the detergent dispenser. Set and start a programme for cotton at the highest temperature without laundry. This removes all possible dirt from the drum and the tub.

USING THE APPLIANCE

1. Open the water tap.
2. Connect the mains plug to the mains socket.
3. Press button 1 to activate the appliance.
4. Put the laundry in the appliance.
5. Use the correct quantity of detergent and additives.
6. Set and start the correct programme for the type of laundry and soil.

LOADING THE LAUNDRY

1. Open the appliance door.
2. Put the laundry in the drum, one item at a time. Shake the items before you put them in the appliance. Make sure not to put too much laundry in the drum.
3. Close the door.



Make sure that no laundry stays between the seal and the door. There is a risk of water leakage or damage to the laundry.

FILLING THE DETERGENT AND ADDITIVES



I	The detergent compartment for the prewash phase and the soak programme. Add the detergent for prewash and soak before the start of the programme.
II	The detergent compartment for the washing phase. If you use a liquid detergent, put it immediately before you start the programme.
	Liquid additives compartment (fabric conditioner, starch). Put the product in the compartment before you start the programme.
MAX	This is the maximum level for the quantity of liquid additives.
	The compartment for the stain remover. Put the product in the compartment and set the stain function before you start the programme.
	Flap for powder or liquid detergent Turn it (up or down) in the correct position to use powder or liquid detergent.
	Always obey the instructions that you find on the packaging of the detergent products.

Check the position of the flap



1. Pull out the detergent dispenser until it stops.
2. Press the lever down to remove the dispenser.





3. To use powder detergent, turn the flap up.

4. To use liquid detergent, turn the flap down.

With the flap in the position DOWN:

- Do not use gelatinous or thick liquid detergents.
- Do not put more liquid detergent than the limit showed in the flap.
- Do not set the prewash phase.
- Do not set the delay start function.

5. Measure out the detergent and the fabric conditioner.
6. Carefully close the detergent dispenser. Make sure that the flap does not cause a blockage when you close the drawer.

SETTING AND STARTING A PROGRAMME

1. Turn the programme knob. The related programme indicator comes on.
2. The indicator of button 4 flashes with red colour.
3. The display shows the default temperature, the spin speed and the empty indicator bars of the available functions.
4. To change the temperature and/or the spin speed, press the related buttons.
5. Set the available functions.
6. Press button 4 to start the programme. The indicator of button 4 is on.

The appliance adjust automatically the cycle time to the laundry you have put in the drum to have perfect washing results in the minimum necessary time. After approximately 15 minutes from the start of the programme, the display shows the new time value.

INTERRUPT A PROGRAMME

1. Press button 4 . The indicator flashes.
2. Press button 4 again. The washing programme continues.

CANCEL A PROGRAMME

1. Press button 1 to cancel the programme and to deactivate the appliance.
2. Press button 1 again to activate the appliance. Now, you can set a new washing programme.

The appliance does not drain the water.

CHANGE A FUNCTION

You can change only some functions before they operate.

1. Press button 4 . The indicator flashes.
2. Change the function set.

SET THE DELAY START

1. Press button 5 again and again until the display shows the number of minutes or hours. The related symbols comes on.
2. Press button 4 , the appliance starts the countdown of the delay start.

   When the countdown is completed, the programme starts automatically.

Before you press button 4 to start the appliance, you can cancel or change the set of the delay start.
You cannot set the delay start with the **Steam** programme.

CANCEL THE DELAY START

1. Press button 4 . The related indicator flashes.
2. Press button 5 again and again until the display shows **0'**.
3. Press button 4 . The programme starts.

OPEN THE DOOR

While a programme or the delay start operates, the appliance door is locked.

To open the appliance door:

1. Press button 4 . The door lock symbol in the display goes off.
2. Open the appliance door.
3. Close the appliance door and press button 4 . The programme or the delay start continues.

If the temperature and level of the water in the drum are too high, the door lock symbol stays on and you cannot open the door. To open the door do the steps that follow:

1. Deactivate the appliance.
2. Wait for some minutes.
3. Make sure that no water is in the drum.

If you deactivate the appliance, it is necessary to set the programme again.

AT THE END OF THE PROGRAMME

- The appliance stops automatically.
- The acoustic signals operate.
- In the display 0 comes on.
- The indicator of the Start/Pause button 4 goes off.
- The door lock symbol goes off.
- Press button 1 to deactivate the appliance. After five minutes from the end of the programme, the energy saving function automatically deactivates the appliance.

When you activate the appliance again, the display show the end of the last set programme. Turn the programme knob to set a new cycle.

- Remove the laundry from the appliance. Make sure that the drum is empty.

- Keep the door ajar, to prevent mildew and odours.
- Close the water tap.

The washing programme is completed, but there is water in the drum:

– The drum turns regularly to prevent the creases in the laundry.
– The door stays locked.
– You must drain the water to open the door.

To drain the water:

1. If necessary, decrease the spin speed.
2. Press the Start/Pause button 4 . The appliance drain the water and spin.
3. When the programme is completed and the door lock symbol goes off, you can open the door
4. Deactivate the appliance.

The appliance drain and spin automatically after approximately 18 hours.

HELPFUL HINTS AND TIPS

THE LAUNDRY LOAD

- Divide the laundry in: white, coloured, synthetics, delicates and wool.
- Obey the washing instructions that are on the laundry care labels.
- Do not wash together white and coloured items.
- Some coloured items can discolour with the first wash. We recommend that you wash them separately for the first times.
- Button up pillowcases, close zippers, hooks and poppers. Tie up belts.
- Empty the pockets and unfold the items.
- Turn inside out multilayered fabrics, wool and items with painted illustrations.
- Remove hard stains.
- Wash with a special detergent heavy soil stains.
- Be careful with the curtains. Remove the hooks or put the curtains in a washing bag or pillowcase.
- Do not wash in the appliance :
  - Laundry without hems or with cuts
  - Underwired bras.
  - Use a washing bag to wash small items.
- A very small load can cause balance problems with the spin phase. If this occurs, adjust manually the items in the tub and start the spin phase again.

STUBBORN STAINS

For some stains, water and detergent is not sufficient.
We recommend that you remove these stains before you put the items in the appliance.
Special stain removers are available.
Use the special stain remover that is applicable to the type of stain and fabric.

DETERGENTS AND ADDITIVES

- Only use detergents and additives specially made for washing machines.
- Do not mix different types of detergents.
- To help the environment, do not use more than the correct quantity of detergent.
- Obey the instructions that you find on the on packaging of these products.
- Use the correct products for the type and colour of the fabric, the programme temperature and the level of soil.
- If you use liquid detergents, do not set the prewash phase.
- If your appliance has not the detergent dispenser with the flap device, add the liquid detergents with a dosing ball.

WATER HARDNESS

If the water hardness in your area is high or moderate, we recommend that you use a water softener for washing machines. In areas where the water hardness is soft it is not necessary to use a water softener.
To know the water hardness in your area, contact your local water authority.
Obey the instructions that you find on the packaging of the products.
Equivalent scales measure the water hardness:

- German degrees (°dH).
- French degrees (°TH).
- mmol/l (millimol for each litre - international unit for the hardness of water).
- Clarke degrees.

Water hardness table

Level	Type	Water hardness			
		°dH	°T.H.	mmol/l	Clarke
1	soft	0-7	0-15	0-1.5	0-9
2	medium	8-14	16-25	1.6-2.5	10-16
3	hard	15-21	26-37	2.6-3.7	17-25
4	very hard	> 21	> 37	>3.7	>25

CARE AND CLEANING

WARNING!

Disconnect the appliance from the mains supply before you clean it.

DESCALING

The water we use contains limescale. If it becomes necessary, use a water softener to remove limescales.
Use a special product made for washing machines. Obey the instructions that you find on the packaging of the manufacturer.
Do this separately from the laundry wash.

EXTERNAL CLEANING

Clean the appliance only with soap and warm water. Fully dry all the surfaces.

CAUTION!
Do not use alcohol, solvents or chemical products.

MAINTENANCE WASH

With the low temperature programmes it is possible that some detergent stays in the drum. Make regularly a maintenance wash. To do this:

- Empty the laundry from the drum.
- Set the hottest cotton wash programme
- Use a correct quantity of powder detergent with biological properties.

After each wash, keep the door open for a while to prevent mould and to let unpleasant smells go out.

DOOR SEAL



Regularly examine the seal and remove all objects from the inner part.

DRUM

Regularly examine the drum to prevent limescale and rust particles.
Only use special products to remove rust particles from the drum.
To do this:

- Clean the drum with special product for stainless steel.
- Start a short programme for cotton at the maximum temperature with a small quantity of detergent.

DETERGENT DISPENSER

To clean the dispenser:



1. Press the lever.
2. Pull the dispenser out.



3. Remove the top part of the liquid additive compartment.
4. Clean all the parts with water.



5. Clean the dispenser recess with a brush.
6. Put back the dispenser in the recess.

DRAIN PUMP

Regularly examine the drain pump and make sure that it is clean.

Clean the pump if:

- The appliance does not drain the water.
- The drum cannot turn.
- The appliance makes an unusual noise because of the blockage of the drain pump.
- The display shows an alarm code because of the problem with water drain.

WARNING!

1. Disconnect the mains plug from the mains socket.
2. Do not remove the filter while the appliance operates. Do not clean the drain pump if the water in the appliance is hot. The water must be cold before you clean the drain pump.

To clean the drain pump:



1. Open the drain pump door.



2. Pull the flap out to remove it.



3. Put a container below the recess of the drain pump to collect the water that flows out.
4. Press the two levers and pull forward the drainage duct to let the water flow out.



5. When the container is full of water, put the drainage duct back again and empty the container. Do steps 4 and 5 again and again until no more water flows out from the drain pump.
6. Pull back the drainage duct and turn the filter to remove it.



7. Remove fluff and objects from the pump.



8. Make sure that the impeller of the pump can turn. If this does not occur, contact the service centre.



9. Clean the filter under the water tap and put it back in the pump into the special guides.
10. Make sure that you tighten correctly the filter to prevent leakages.
11. Put the flap back and close the drain pump door.

THE INLET HOSE FILTER AND THE VALVE FILTER

It could be necessary to clean the filters when:

- The appliance does not fill with water.
- The appliance fills with the water for a long time.
- The indicator of button 4 flashes and the display shows the related alarm. Refer to 'Troubleshooting'.

WARNING!
Disconnect the mains plug from the mains socket.

To clean the water inlet filters:



1. Close the water tap.
2. Remove the water inlet hose from the water tap.
3. Clean the filter in the inlet hose with a stiff brush.



4. Remove the inlet hose behind the appliance.
5. Clean the filter in the valve with a stiff brush or a towel.



6. Install again the inlet hose. Make sure that the couplings are tight to prevent leakages.
7. Open the water tap.

EMERGENCY DRAIN

Because of a malfunction, the appliance cannot drain the water.
If this occurs, do steps (1) through (6) of 'To clean the drain pump'.

If necessary, clean the pump.
Put the drainage duct back and close the drain pump flap.

When you drain the water with the emergency drain procedure, you must activate again the drain system:

1. Put 2 litres of water in the main wash compartment of the detergent dispenser.
2. Start the programme to drain the water.

FROST PRECAUTIONS

If the appliance is installed in an area where the temperature can be less than 0 °C, remove the remaining water from the inlet hose and the drain pump.

1. Disconnect the mains plug from the mains socket.
2. Close the water tap.
3. Remove the water inlet hose
4. Put the two ends of the inlet hose in a container and let the water flow out of the hose.
5. Empty the drain pump. Refer to the emergency drain procedure
6. When the drain pump is empty, install the inlet hose again.

WARNING!
Make sure that the temperature is more than 0 °C before you use the appliance again.
The manufacturer is not responsible for damages caused by low temperatures.

TROUBLESHOOTING

The start of the appliance does not occur or it stops during operation.
First try to find a solution to the problem (refer to the table). If not, contact the service centre.

With some problems, the acoustic signals operate and the display shows an alarm code:

- E10 - The appliance does not fill with water.
- E20 - The appliance does not drain the water.
- E40 - The appliance door is open or not closed correctly.
- EF0 - The anti-flood device is on.

WARNING!
Deactivate the appliance before you do the checks.

Problem	Possible cause	Possible solution
The appliance does not fill with water.	The water tap is closed.	Open the water tap.
	The water inlet hose is damaged.	Make sure that the water inlet hose has no damages.
	The filters in the water inlet hose is blocked .	Clean the filters. Refer to 'Care and cleaning'.
	The water tap is blocked or is furred with limescale.	Clean the water tap.
	The connection of the water inlet hose is not correct.	Make sure that the connection is correct.
	The water pressure is too low.	Contact your local water authority.
The appliance does not drain the water.	The water drain hose is damaged.	Make sure that the water drain hose has no damages.
	The filter of the drain pump is blocked.	Clean the filter of the drain pump. Refer to 'Care and cleaning'.
	The connection of the water drain hose is not correct.	Make sure that the connection is correct.
	A washing programme without the drain phase is set.	Set the drain programme.
	The function Rinse & Hold is on.	Set the drain programme.
The appliance door is open or not closed correctly.		Close the door correctly.

Problem	Possible cause	Possible solution
The anti-flood device is on.		• Disconnect the appliance. • Close the water tap. • Contact the service centre.
The spin phase does not operate.	The spin phase is off.	Set the spin programme.
	The filter of the drain pump is blocked.	Clean the filter of the drain pump. Refer to 'Care and cleaning'.
	Balance problems with the laundry load.	Adjust manually the items in the tub and start the spin phase again.
The programme does not start.	The mains plug is not connected in the mains socket.	Put in the mains plug.
	Blow out fuse in the household fuse box.	Replace the fuse.
	You did not press button 4 .	Press button 4 .
	The delay start is set.	To start immediately the programme, cancel the delay start.
	The Child Lock function is activated.	Deactivate the Child Lock function.
There is water on the floor.	Leakages from the couplings of the water hoses.	Make sure that the couplings are tight.
	Leakages from the drain pump.	Make sure that the drain pump filter is tight.
	The water drain hose is damaged.	Make sure that the water inlet hose has no damages.
You cannot open the appliance door.	The washing programme is in operation.	Let the washing programme end.
	There is water in the drum.	Set the drain or the spin programme.
The appliance makes an unusual noise.	Incorrect level of the appliance.	Adjust the level of the appliance. Refer to 'Installation'.
	You did not remove the packaging and/or the transit bolts.	Remove the packaging and/or the transit bolts. Refer to 'Installation'.
	The load is very small.	Add more laundry in the drum.

Problem	Possible cause	Possible solution
The appliance fills with water and drain immediately.	The end of the drain hose is too low.	Make sure that the drain hose is in the correct position.
The washing results are not satisfactory.	The detergent you used was not sufficient or correct.	Increase the detergent quantity or use a different one.
	You did not remove the stubborn stains before you wash the laundry.	Use special products to remove the stubborn stains.
	Incorrect temperature was set.	Make sure that you set the correct temperature.
	Too much laundry load.	Decrease the laundry load.

After the check, activate the appliance. The programme continues from the point of interruption.
If the problem occurs again, contact the service centre.

If the display shows other alarm codes, contact the service centre.

INSTALLATION

UNPACKING



1. Use the gloves. Remove the external film. If necessary, use a cutter.



2. Remove the cardboard top.

3. Remove the polystyrene packaging materials.



4. Remove the internal film.



5. Open the door. Remove the polystyrene piece from the door seal and all the items from the drum.



6. Put the front piece on the floor behind the appliance. Carefully put down the appliance with the rear side on it. Make sure not to damage the hoses.



7. Remove the polystyrene protection from the bottom.
8. Pull up the appliance in vertical position.



9. Remove the power supply cable and the drain hose from the hose holders.



10. Remove the three bolts. Use the key supplied with the appliance.
11. Pull out the plastic spacers.



12. Replace the plastic spacers with the plastic caps. You can find these caps in the user manual bag.

WARNING!
Remove all the packaging and the transit bolts before you install the appliance.

We recommend that you keep the packaging and the transit bolts for when you move the appliance.

POSITIONING AND LEVELLING



- Install the appliance on a flat hard floor.
- Make sure that carpets do not stop the air circulation below the appliance.
- Make sure that the appliance does not touch the wall or other units
- Loosen or tighten the feet to adjust the level. A correct adjustment of the appliance level prevents the vibration, noise and the movement of the appliance when in operation.



- The appliance must be level and stable.

CAUTION!
Do not put cardboard, wood or equivalent materials below the appliance feet to adjust the level.

THE INLET HOSE



- Connect the hose to the appliance. Turn the inlet hose only left or right. Loose the ring nut to set it in the correct position.



- Connect the water inlet hose to the cold water tap with 3/4 thread.

CAUTION!
Make sure that there are no leaks from the couplings.

Do not use an extension hose if the inlet hose is too short. Contact the service centre for the replacement of the inlet hose.

Water-stop device



The inlet hose has a water stop device. This device prevents water leaks in the hose because of its natural ageing. The red sector in the window «A» shows this fault .
If this occur, close the water tap and contact the service centre to replace the hose.

WATER DRAINAGE

There are different procedures to connect the drain hose:

With the plastic hose guide.





- On the edge of a sink.
- Make sure that the plastic guide cannot move when the appliance drains. Attach the guide to the water tap or the wall.



- To a stand pipe with vent-hole.

  Refer to the illustration. Directly into a drain pipe at a height of not less than 60 cm and not more than 100 cm. The end of the drain hose must always be ventilated , i.e. the inner diameter of the drainpipe must be larger than the external diameter of the drain hose.

Without the plastic hose guide.



- To a sink spigot.

  Refer to the illustration. Put the drain hose in the spigot and tighten it with a clip. Make sure that the drain hose makes a loop to prevent that remaining particles go in the appliance from the sink.



- Directly to a built-in drain pipe in the room wall and tighten it with a clip.

You can extend the drain hose to maximum 400 cm. Contact the service centre for the other drain hose and the extension.

www.aeg.com/shop

132933290-A-252011

CE